



ZM 200 Series Training

Sunday, November 05, 2017

Avery Weigh-Tronix

ZM200 Series Training Agenda

- ZM200 Series Models
- Mechanical Review - Assembly
- System Hardware & Components
- Hardware Connections & Jumper Settings
- PC setup of Serial and Ethernet ports
- Passwords, Key Functions & Menu Navigation
- User, About, Audit Menus
- Diagnostics – Scale A/D , Serial , Setpoint I/O
- Setup Menu
- Calibration & Scale Metrology

ZM200 Series Training Agenda

- Alternate Calibration
- Custom Units of Measure
- Filtering
- System Menu
- Tare Settings
- Communication Ports
- Ethernet: TCP/IP
- Protocol Configuration
- Print Formats – Front Panel Editing
- Print Tokens and Parameters

ZM200 Series Training Agenda

- Enquiry, SMA, NCI protocols
- Remote Inputs and Setpoint Outputs
- Applications
 - Accumulator, Counting, Target, Batching
 - Peak, Remote Display
- ZM201 NiMH Battery Option & Sealing Kit
- ZM201 Signal Processor
 - PC Application – Remote Cal / Wt Simulator
- ZM205 Baggage Scale

ZM200 Series Training Agenda

- Service & User Manuals
- Ztools / Zcom / Zport
 - Firmware Updates / Configuration Files
- Other Tech Guides
- Final Review - Model Comparisons

ZM201 & ZM205 models

- ZM201-SD2
- ZM201-PD2 -> Large LCD
- ZM201-SP2
- ZM201-SP0
- ZM205-SP2
- ZM205-SR2

1st digit

S = Stainless

P = ABS Plastic

2nd digit

D = Desktop

P = Panel Mount

R = Remote Display

3rd digit

0 = No display

2 = TN Green Backlit LCD

Model code: serial tags and shipping labels

Avery Weigh-Tronix

SD2 - Stainless Steel



Avery Weigh-Tronix

PD2 – ABS Plastic



[ZM201 ABS Pole Mount](#)

Avery Weigh-Tronix

PD2 – Back Connections



Avery Weigh-Tronix

SP2 - Panel Mount



Avery Weigh-Tronix

SP0 - Signal Processor



Avery Weigh-Tronix

ZM205 – Baggage Scale



Avery Weigh-Tronix

Panel Mount – Rear Connections



ZM201-SP2

ZM201-SP0

ZM205-SP2

ZM205-SR2

Avery Weigh-Tronix

ZM200 Family



Avery Weigh-Tronix

ZM201's



Avery Weigh-Tronix

ABS-PD2 disassembly


Remove 4 phillips head screws from corners

Remove 3 green two-part connectors – use flat head screwdriver

Do not need to remove battery compartment screws


Separate the 2 halves

Be careful of lose screws!



Avery Weigh-Tronix

ABS-PD2 Assembly




SST-SD2 disassembly

Remove the 14 Acorn Nuts using a 7mm socket driver

Remove the tethered ground strap on inside of backplate

Do not lose your acorn nuts!

SST-SD2 Assembly




SST-SD2 Back Cover / Acorn Nuts

7mm socket - Torque to 6 in-lb


Finger tighten all nuts first...follow pattern shown

Approximately 1/4 turn after finger tight = 6 in-lb



Avery Weigh-Tronix

Display Boards



PD2 model
30mm (1.2 ") digits

SD2 and SP2 models
13mm (0.5") digits

Avery Weigh-Tronix

Model select jumpers

Display Select jumper:

Place on Pins 1 & 2 for the large ABS housing display.

Remove the jumper for the small display of the stainless steel desktop and panel mount indicators.

Jumper shown in the OFF position.

Seal Switch jumper:

Photo shows the jumpers in the ON or SEALED position. Remove the jumper to unseal the indicator.

Sense (Excitation) jumpers:

4 wire loadcells require jumpers to be ON the pins.
6 wire loadcells require jumpers to be OFF the pins.

Photo shows the jumpers in the OFF position.

'Always ON' jumper:

Place jumper on pins 1 & 2 when the indicator is AC powered. If there is AC power, the unit will be ON.

Remove jumper when DC powered and the ON/OFF key will turn the unit on and off.


Ethernet Power jumpers:

Leave in the OFF position. These are used for the ZM205 only.

DS1: Blinks once/second when all is OK


DS2: Blinks when there is ethernet data transfer.

DS3: Lights when the ethernet is connected.




Model select jumpers


ZM201-PD2




ZM201-SD2




ZM201-SP0



ZM201-SP0



**Sets default IP
192.168.1.15**



Which model is this?

Model	S1-1	S1-2	S1-3
ZM201-SD2	ON	OFF	OFF
ZM201-PD2	ON	OFF	ON
ZM201-SP0	OFF	OFF	OFF
ZM201-SP0 Default IP	OFF	OFF	ON

Avery Weigh-Tronix

AC/DC Power Supply

ZM201 SST (SD2) model only

- Wide-Range AC Input 90-264 VAC
- Small Footprint - 3.5"x 2"x 0.85"
- Conducted EMI exceeds FCC and CISPR 22 Class B requirements
- Approved to UL60950-1: 2003, CSA-22.2, No. 60950-1-03, IEC and EN60950-1
- Class B Rating
- RoHS Compliant
- CE marking for LVD
- Same Mfg as Z 3xx series

Rated Output 20 watts

International Safety Standard Approvals



Avery Weigh-Tronix

SST model Glands


- | | | |
|---|-------------------|--|
| 1 | PG13.5 | Load cell |
| 2 | PG7 | Com Ports or I/O |
| 1 | PG11 | Power cord |
| 1 | NPT $\frac{3}{4}$ | 26.67 mm (1.05") dia
Conduit connection
Ethernet QD option |



Avery Weigh-Tronix

Block Diagram

Always ON when jumper installed (AC)
Remove to use ON/OFF switch (DC/Battery)



Avery Weigh-Tronix

External Connections

Same connections as Z 3xx series

Scale Interface	
TB1	Description
1	-EXC
2	+EXC
3	-SEN
4	+SEN
5	-SIG
6	+SIG
7	SHIELD

Input / Output	
TB2	Description
1	GND
2	Input 1
3	Input 2
4	Input 3
5	Digital Out 1
6	Digital Out 2
7	Digital Out 3
8	Relay Voltage

Com 1 & 2 RS232	
TB3	Description
1	GND
2	TX1
3	TX2
4	RX1
5	RX2
6	5VDC

Load Cell connection

Scale Interface	
TB1	Description
1	-EXC
2	+EXC
3	-SEN
4	+SEN
5	-SIG
6	+SIG
7	SHIELD

Black
Green or Red

Red or Green
White
Shield

Do not connect the Sense leads
Observe weight
Did you get upper dashes only?
Connect Sense jumpers P1 & P2

Avery Weigh-Tronix

Load Cell connection

Scale Interface		
TB1	Description	
1	-EXC	Black
2	+EXC	Green
3	-SEN	Blue
4	+SEN	Yellow
5	-SIG	Red
6	+SIG	White
7	SHIELD	Shield

Remove Sense jumpers
Connect the Sense wires

Scale Interface Test

1. Set LC SIM to 0 mV/V (full CCW) and ZERO scale
2. Rotate LC Simulator Clockwise – weight should increase
3. Set LC SIM to 1mV / V – display should be ~ 2500 kg

Serial RS232

Com 1 & 2 RS232	
TB3	Description
1	GND
2	TX1
3	TX2
4	RX1
5	RX2
6	5VDC

Black

Red

Green

PC Serial Cable 47355-0010MTS


[Hercules COM Setup](#)

Avery Weigh-Tronix

Serial RS232 Test

1. Open Hercules and select SERIAL tab
2. Check Settings – defaults should match ZM
3. Select OPEN
4. Press PRINT key on ZM → PF #1 = GTN

[Hercules](#)



Right click in Received data window

Toggle between ASCII and Hex chars

Try different Special Char settings


Avery Weigh-Tronix

Ethernet Connection

Follow this simple diagram to connect your laptop to the cable

PC LAN Setup

Quick access to LAN setup
Run "ncpa.cpl"



Color Code

Black	B	Red/Black	R/B
White	W	Red/White	R/W
Brown	Br	Red/Green	R/G
Blue	L	Red/Yellow	R/Y
Red	R	Red/Brown	R/Br
Green	G	Green/Black	G/B
Yellow	Y	Green/White	G/W
Orange	O	Green/Yellow	G/Y
Dark green	Dg	Green/Red	G/R
Sky blue	Sb	Green/Orange	G/O
Grey	Gr	Blue/Black	L/B
Pink	P	Blue/White	L/W
Black/White	B/W	Blue/Red	L/R
Brown/Black	Br/B	Blue/Yellow	L/Y
Brown/White	Br/W	Blue/Orange	L/O
Brown/Gray	Br/Gr	Blue/Brown	L/Br
Yellow/Black	Y/B	Orange/White	O/W

Ethernet Connection

Ping test


Start Button



Type “cmd” in “Search programs and files”



or in Run -> Open”



Ethernet Connection

Ping test

[Ping 192.168.1.21](#)

201 Key Functions

	Weigh mode - Press the TARE key to perform a tare function or the key prompts for a preset tare, if enabled. Menu Navigation - Acts as an up arrow key for menu navigation. Numeric entry - Increments a value. Allows you to access minus sign and comma.
	Weigh mode - Press the SELECT key to toggle between Gross, Net, Tare and any other active display values. Menu Navigation - Press and hold to enter the setpoint editor. Acts as a down arrow key. Numeric entry - Decrements a value. Allows you to access minus sign and comma.
	Weigh mode - Press the PRINT to send information to a peripheral device. Performs accumulator function, if enabled. Menu Navigation - Acts as a left arrow key. Numeric entry - Functions as a backspace.
	Weigh mode - Press the UNITS key to scroll through the active units of measure. Menu Navigation - Acts as a right arrow key. Numeric entry - Inserts a new digit and moves the cursor position to the right.
	Press the ZERO key to zero the display. Acts as an ENTER key to accept a displayed value or function. Also used to access the Quick Code entry for menu navigation.
	Press and hold F1 to view the password entry screen. Press to select application specific choices. Aborts a numeric entry and acts as an ESCAPE key for menu navigation.
	If DC powered, press to turn the indicator on. Press and hold for two seconds to turn the indicator off. P3 jumper on main PCB must be removed for ON/OFF key to function. If P3 jumper is in place, when power is applied to the indicator it will be on.

Avery Weigh-Tronix

Z Series Key Navigation

Press **SELECT**/ ▼ to move down in a menu

Press **TARE**/ ▲ to move up in a menu, except at the bottom item in a menu, then use **ZERO**/ ← or **F1**


Press **PRINT**/ ◀ to move left in a menu

Press **UNITS**/ ▶ to move right in a menu

Press **ZERO**/ ← to accept a value or choice and move up in the menu.

Press **F1** to escape and move up in the menu

E1005 Key Navigation



Key Navigation Arrows



Numeric Entry

 These segments flash in numeric entry mode

TARE / ▲ – Press to increment the flashing number

SELECT / ▼ – Press to decrement the flashing number

PRINT / ◀ – Press to backspace cursor in a number

UNITS / ▶ – Press to advance cursor in a number

ZERO / ↵ – Press to accept a value

F1 / ESC – Press to escape an entry screen

TARE ↑ increments flashing digit 0 -> 1 -> 2 -> 3....

SELECT ↓ decrements flashing digit 0 -> “-” -> 9 -> 8 -> 7

UNITS → adds “0”

PRINT ← removes last digit

Passwords

Password	Menu Level	Accessed Menus
111	USER	User, About, Audit
3570	DIAGNOSTICS	Diag, User, About, Audit
3088	ADMIN	Setup, Diag, User, About, Audit
2580	CALIBRATE	Calib
1793	SUPER	Application specific items. See User manual.

[Numeric Entry](#)

Avery Weigh-Tronix

Bar Graph segments

All Segments Flashing

In a menu screen...use Navigation keys



Center Flashing / Others Off

In a numeric entry screen



Right Flashing / Others Off

In a preset list menu...use PRINT and UNITS



Left Flashing / Others Off

In a string index...use String Index action chart



Every Alternate Segment Flashing

Octet entry for IP, Subnet or Gateway address.



Avery Weigh-Tronix

Setup password entry

TARE ↑ increments : SELECT ↓ decrements : UNITS → add "0" : PRINT ← remove digit

Example: key in the password 3088

NOTE: 5 secs w/o key press aborts entry

Press & hold **F1** key until **PASS** is displayed, then release...

Flashing **0** is displayed

Press **TARE** until **3** is displayed

Press **UNITS** to insert a **0**

Press **UNITS** again to insert another **0**


Press **SELECT** until **8** is displayed

Press **UNITS** to insert a **0**

Press **SELECT** until **8** is displayed

Press **ZERO** to access the **SETUP** menu

Quick Access Codes




From “SETUP”
Press and hold ZERO > “P 0”

Release and enter quick access
code number

With 0 flashing press SELECT for “.”

Avery Weigh-Tronix

User Menu - 111



SELECT = ▼

TARE = ▲

PRINT = ◀

UNITS = ▶


ZERO = ←

F1 = Escape or ▲

Set correct Time & Date
for your office location

Avery Weigh-Tronix


About Menu




Avery Weigh-Tronix

Audit Menu

Category II Audit Trail




Diagnostics Menu - 3570




Install jumper between
9p Cable pins 2 and 3
TB3 pins 2 and 4 for COM 1
TB3 pins 3 and 5 for COM 2
perform the loopback test

Avery Weigh-Tronix

Setup Menu - 3088



Calibration Menu



SELECT = ▼

TARE = ▲

PRINT = ◀


UNITS = ▶

ZERO = ←


F1 = Escape or ▲

Avery Weigh-Tronix

Scale Menu




Calibration Menu



Alternate Calibration

Avery Weigh-Tronix

Scale Menu




[Filtering Video](#)

[Filtering](#)


[Custom UOM](#)

SELECT = ▼
TARE = ▲
PRINT = ◀
UNITS = ▶
ZERO = ←
F1 = Escape or ▲

System Menu



System > Site, Display, Buttons




Site - Default Settings

	USA	GB	CAN	EU	CHINA	INDIA
Capacity	5000	2500	2500	2500	2500	2500
Division	1	0.5	0.5	0.5	0.5	0.5
Unit of measure	lb	kg	kg	kg	kg	kg
Unit of measure 2	kg	off	off	off	off	off
Cal unit	lb	kg	kg	kg	kg	kg
Cal wt	5000	2500	2500	2500	2500	2500
Zero Range	100	2	2	2	2	2
Over Basis	Percent	Division	Percent	Division	Division	Division
Separator	decimal	decimal	decimal	comma	decimal	decimal
Date Format	MM-DD-YY	DD-MM-YY	DD-MM-YY	DD-MM-YY	DD-MM-YY	DD-MM-YY
Time Format	12 Hr	24	24	24	24	24
Average	10	10	10	10	10	10
Filter Constant	1	1	1	1	1	1
Filter Threshold	100	50	50	50	50	50
Under Cap. Div.	250	20	250	250	250	250
AZT Div.	3	.25	3	3	3	3
Motion Div.	3	.25	3	3	3	3
App	General	General	General	General	General	General

Avery Weigh-Tronix

System > D-Val, Tare, Config



Avery Weigh-Tronix

Key Entry Tare

Must be enabled in SETUP > SYSTEM > TARE menu


1. Press SELECT key
TARE annunciator displayed

2. Press the TARE key

3. Scroll in Tare menu
Procedure

4. Press the ZERO key to accept the value


5. Display indicates NET weight




[Tare Entry](#)

Avery Weigh-Tronix

System > Serial, App, Password



System > Z-Lock




1. Enable ON
2. Set timer to 1 min
3. Exit & save
4. Add weight & wait

Restore setting -> ENABLE OFF




Ports Menu

Serial



Ports > Ethernet




Default IP 192.168.1.21
Subnet 255.255.255.0
Gateway 0.0.0.0
DHCP = OFF

Port # usually assigned by IT
Host IP required for Client mode



Avery Weigh-Tronix



Ports > Protocol




TCP/IP Test



[TCP/IP Communication](#)

Avery Weigh-Tronix


Ports > P.F. Editor



- 1 General APP – GTN
- 2 Accumulator - GTN and transaction count
- 3 Count
- 4 Checkweigh - Net wt
- 5 Batch - Displayed wt
- 6 Peak – Gross Peak wt
- 7 Remote Display – Displayed wt (Master)
- 8 Total - Accumulator App (Press & Hold PRINT)
- 9 Total – Count App (Press & Hold PRINT)
- 10 Blank

Avery Weigh-Tronix

Ports > AutoPrint / RTZ Interlock




Auto Print / Accum & Print Return to Zero
use Gross Zero Band to re-arm

Auto Print requires Protocol TYPE = PRINT


Auto Accum only applies when APP = ACCUM

Auto Accum also does Auto Print
...so if both are ON it will print twice


Protocol Types




Binding



Protocol Attributes




Protocol Examples



Can you help me figure out how to set this up?


Avery Weigh-Tronix

Serial Printer example




Avery Weigh-Tronix

Remote Display example



Ethernet example



E-NET setup : TCP/IP
Connection: Port #, Server
or Client using SMA addressing

Avery Weigh-Tronix

Print Formatting

Create new or modify existing print formats

- System and Application Variables -> referred to as Tokens

- ASCII characters

- Control Codes

Append option parameters to modify default behavior

- Width or number of digits / characters

- Spaces / leading zeros

- Alternate units of measure

- High resolution format

- Rounded weight

- Omit decimal point

- Printed format – Time & Date

String Indexing / Character Edit

Table 1: Key Action When In The String Index Select Mode						
Action	TARE	SELECT	ZERO	PRINT	UNITS	F1
Momentary Key Press	Does nothing	Selects the index character for editing using the key actions in Table 2	Nice Exit	Moves left one position in the index	Moves right one position in the index	ESC/Abort
Long Key Press	Deletes current character	Insert new character after this point Default character added is 32 (space)	Does nothing	Page Up (Decrements index by 10)	Page Down (Increments index by 10)	Does nothing

After you select the index number, use the Table 2 key actions to edit the character for that index number.

Table 2: Key Action When In The Character Edit Mode						
Action	TARE	SELECT	ZERO	PRINT	UNITS	F1
Single Key Press	Increments the flashing digit by 1	Decrements the flashing digit by 1	Enter	Delete flashing digit	Add Digit	ESC/Abort
Long Key Press	Move flashing digit left	Move flashing digit right	Does nothing	Delete the entire entry	Does nothing	Does nothing

Print Format example

Add the company name **AWTX** to Print Format #1...GTN

Start by adding up the number of characters needed including any spaces, carriage returns and line feeds.

A	V	E	R	Y	Cr	Lf	← Text, etc. to insert
1	2	3	4	5	6	7	← Number of characters to insert
65	86	69	82	89	13	10	← Decimal value to enter

SETUP > PORTS > P.F.EDIT > PRNFT 1 > Press SELECT



Index # , (Token) Character
Token 1 = Gross Wt

Avery Weigh-Tronix

Insert Spaces

Press and hold the SELECT key to insert characters
(space = decimal 32)

Index # will increment by 1 every second as spaces are inserted

For this example we needed 6 spaces

Press and hold SELECT key until display shows...



Reposition Index Position

Press PRINT to navigate back up to Index Position #1



Press SELECT to start character edit



NOTE: Press & Hold PRINT or UNITS speeds up
Index position navigation Avery Weigh-Tronix

Edit Characters

A	W	T	X	Cr	Lf	←	Text, etc. to insert
1	2	3	4	5	6	←	Number of characters to insert
65	87	84	88	13	10	←	Decimal value to enter

Enter 65 and press ZERO



1. Press UNITS to advance to next Index position
2. Press SELECT > 2, 32 is displayed
3. Enter decimal value for next letter > press ZERO.

Repeat steps 1 - 3 until last character is entered > 10 for the line feed.

Edit Characters



PRESS **ZERO** TO COMPLETE THE EDIT!!!
Must return to the “**PRNFT x**” for SAVED EXIT

Exit & SAVE YES

Now test your printout using the serial cable

System & Application Variables

t - System Token

Examples: t1 = Gross, t2 = Tare, t3 = Net, t9 = units
t12 = Count, t200 = Time , t201 = Date

A - App Variable

Examples: A4 = SP Out1, A10 = SP Out1 actual

When a system or application variable is entered, a decimal 49 ("1") is automatically appended to the print string

"1" (49) represents the **VALUE** function of the variable

"2" (50) represents the **NAME** function of the variable

To print the name of the variable change the 49 to 50
or enter the name using ASCII character entry

Optional Parameters

[- Parameter opening bracket Start entry of optional parameters
When an opening bracket “[“ is selected a “]” is automatically appended

] - Parameter closing bracket End entry of optional parameters
Multiple parameters can be inserted in between the [and] brackets

Example: **[W6Z1D2]**

W6 = Width 6 characters

Z1 = Send leading zeros

D2 = Omit decimal point

Insert required number of spaces between brackets, reposition and edit

Variable & Parameter Entry

System or Application variables require knowledge of token number assignments

Parameter options require knowledge of parameter characters and their attributes

Have SERVICE manual available!

Special entry procedures are necessary to insert System or Application variables and optional parameters

**Have SERVICE manual available!!!
Or use Ztools**

Avery Weigh-Tronix

Exercise: Add Time to example

Add Time to the 2nd line

Remember to add spaces, carriage returns, line feeds as needed for proper alignment

P.F.Edit > Press **SELECT** > **1** > Press **SELECT**

1. Press **UNITS** to scroll to the required string index position... "**8,t 001**"
2. Press and hold **SELECT** to insert 3 spaces... "**11,t 001**"
3. Press **PRINT** to return to the previous index position "**8 032**"
4. Press **SELECT** > **32** is displayed
5. Press **PRINT** key twice > **0** to clear value
6. Press **SELECT** until the desired choice is flashing **t** for **System token**
7. Press **UNITS** to shift in a **0**.
8. Enter **200** for **TIME** token...press **ZERO**

NOTE: the value **49** is appended automatically to represent the value


Avery Weigh-Tronix

Exercise: Add Time example

Add carriage return & line feed

9. Press **UNITS** to scroll to the required string index position..."**9,t 32**"
10. Press **SELECT > 32** is displayed
11. Enter **13** for carriage return...press **ZERO**
12. Press **UNITS**..."**10,t 32**"
13. Press **SELECT > 32** is displayed
14. Enter **10** for line feed...press **ZERO**
15. Press **ZERO** to save

Token Function Types



This ASCII number identifies the type of scale token. In this case it identifies the token as the word

Gross




Avery Weigh-Tronix

Token Parameters


A Customer may wish to have the data transmitted with leading zeros and not spaces.
The print format sequence would look like this ...

"1,t 1" Gross Wt token
"2, 50" Name "Gross"



The above token and function will output the text "Gross"

"3,t 1" Gross Wt token
"4, 49" Value



The above token and function will output the Gross weight value.

"5, [" Start parameter
"6, 90" Z Leading Zero



"7, 49" Dec 1 represents
print Leading Zeros
"8,]" End parameter



Avery Weigh-Tronix

System Variables (Tokens)

Token #	Token name	Token Description	Function "1" (dec 49)	Function "2" (dec 50)	Parameter Table
decimal			Value	Name	
1	GWT	Gross Weight	value	"Gross "	WEIGHT
2	SAT	Tare Weight	value	"Tare "	WEIGHT
3	NWT	Net Weight	value	"Net "	WEIGHT
4	MOTN	Motion	"0" stable, "1" motion	"Motion"	INTEGER
5	WST	MotionString	"S" stable, "M" motion	"sMotion"	STRING
6	OVER	Overload	"0" no overload, "1" overload	"Overload"	INTEGER
7	UNDER	Underload	"0" no underload, "1" underload	"Underload"	INTEGER
8	CZ	Center Zero	"0" no center zero, "1" center zero	"Center of Zero"	INTEGER
9	UNIT	Unit	"lb" (or active unit)	"Units"	UNIT
10	PGW	Peak Max weight	value	"Peak Max"	WEIGHT
12	CNT	Count	value	"Count"	INTEGER
13	PCE	Piece Weight	value	"Piece Weight"	WEIGHT

System Variables (cont.)

Token #	Token name	Token Description	Function "1" (dec 49)	Function "2" (dec 50)	Parameter Table
15	WSTAT	Weight Status	"O", "U", "M", "S", "E": see WSTAT table in <i>Additional token tables on page 98</i>	"Weight Status"	WSTAT
16	ACT	Active Display Value	value	active display name	WEIGHT
17	TSAT	Tare Type	"NT", "T", "PT" : see TARE table in <i>Additional token tables on page 98</i>	"Tare Type"	TARE
104	GAT	Accumulated Gross Weight Total	value	"Gross Total"	WEIGHT
105	TAT	Accumulated Tare Weight Total	value	"Tare Total"	WEIGHT
106	NAT	Accumulated Net Weight Total	value	"Net Total"	WEIGHT
107	CAT	Accumulated Count Value Total	value	"Count Total"	INTEGER
200	TIM	Time	value	"Time"	TIME
201	DAT	Date	value	"Date"	DATE
250	OUT1	Output 1		"OUT1"	
251	OUT2	Output 2		"OUT2"	
252	OUT3	Output 3		"OUT3"	
300	RTN	Transaction Count	value	"Transaction Count"	INTEGER
302	CKSM	Checksum	see Checksum table	"Checksum"	CHECKSUM
309	SITE	Site ID	value	"Site ID"	STRING
310	SN	Serial Number	value	"Serial Number"	STRING
311	LK	Condec Units	"L" or "K"		
312	STAT	Condec Status	" " (space) stable, "M" motion, "O" out of range		

System Variables (cont.)

Token #	Token name	Token Description	Function "1" (dec 49)	Function "2" (dec 50)	Parameter Table
313	DIS	AWTX Status Bytes	see DIS table in <i>Additional token tables on page 98</i>	"Status"	DIS
314	UTID	Unique Transaction ID	value	UTID	
500	NULL	Null	null char (dec 0)		
501	SOP	Start Optional Parameters	[		
502	EOP	End Optional Parameters	]		

Application Variables

App Variable	Description	"Function ""1" (dec 49)	"Function ""2" (dec 50)	
4	Output 1	value		FLOAT
5	Output 2	value		FLOAT
6	Output 3	value		FLOAT
10	Output 1 Actual	value	"Actual1"	FLOAT
11	Output 2 Actual	value	"Actual2"	FLOAT
12	Output 3 Actual	value	"Actual3"	FLOAT
13	Remote Input 1		Remote Switch Input 1 Name	INTEGER
14	Remote Input 2		Remote Switch Input 2 Name	INTEGER
15	Remote Input 3		Remote Switch Input 3 Name	INTEGER

Avery Weigh-Tronix

Parameters

Parameter Table	Parameter Description	Parameter character	Default Value	Alternate Values	Comments
WEIGHT	Width	W (87)	7	1 - 9 characters	sets minimum width
	Precision	P (80)	0 = normal precision	0 - 8 characters	sets number of digits right of decimal
	Leading Zero	Z (90)	0 = Leading Spaces	1 = Leading Zeros	
	Sign	p (112)	1 = Show -	2 = Show +	
				3 = Show All	
				4 = Hide All	
	Multiplier	m (109)	0 = None	1 = *10, 2 = *100, 3 = *1000, 4 = *10000, 5 = *100000	
	Decimal Point	D (68)	1 = Show	2 = Hide	
	Justification	J (74)	1 = Right	2 = Left	
	Unit of Measure	u (117)	1 = Current	2 = Calibration unit	allows printing in alternate units
				3 = Rounded current unit	
				4 = Rounded calibration unit	
				5 = Unit 1	
				6 = Unit 2	
	Reset	R (82)		Accumulators and Counters only	clear or reset value after printing
	Round	r(114)	1 = Current	2 = Calibration unit	use metrology compatible rounding of division size for selected unit
				3 = Rounded current unit	
				4 = Rounded calibration unit	
				5 = Unit 1	
				6 = Unit 2	

SMA Commands

Sent	Action	Response
<LF>W<CR>	Weight of the current scale is return.	Standard response (displayed weight)
<LF>P<CR>	Indicator attempts to capture a stable weight on the current scale.	Standard response (displayed weight). W eight is returned as center dashes < ----- > if a stable weight cannot be
<LF>Z<CR>	Indicator attempts to zero the current scale.	Standard response (displayed weight)
<LF>T<CR>	Indicator attempts to tare the current scale.	Standard response (displayed weight)
<LF>T<xxxxxxx.xxx><CR>	The indicator attempts to set the current scale's tare weight to the value that was sent.	Standard response (displayed weight)
<LF>M<CR>	The indicator returns the current scale's Tare weight.	Standard response (tare weight)
<LF>C<CR>	The indicator sets the current scale's Tare weight to zero.	Standard response (gross weight)
<LF>U<CR>	The indicator will cycle the unit of measure on the current scale	Standard response (displayed weight)
<LF>U<uuu><CR>	The indicator will set the unit of measure to <uuu> on the current scale.	Standard response (displayed weight)
<LF>D<CR>	The indicator will return a diagnostic message.	<LF><r><e><c><m><CR> <r> - 'R' (RAM error) or ' ' (space) (RAM ok) <e> - 'E' (EEPROM)
<LF>A<CR>	The indicator will respond with the first line of the About data.	See "About Command Response" (below)
<LF>B<CR>	The indicator will respond with the rest of the About data.	See "About Command Response" (below)
<LF>I<CR>	The indicator will respond with the first line of the scale Information data. (for the current scale)	See "Scale Information Command Response" (below)
<LF>N<CR>	The indicator will respond with the rest of the scale Information data. (for the current scale)	See "Scale Information Command Response" (below)
<ESC>	The indicator will reboot itself	None

W Command response

<LF><s><r><n><m><f><xxxxxx.xxx><uuu><CR>

<LF> Line feed Start of the response message.

<s> Scale Status 'Z' Center of Zero

 'O' Over Capacity

 'U' Under Capacity

 'E' Zero Error

 'T' Tare Error

 <space> None of the above conditions

<r> range Multi-interval range. Always '1' for ZM200 series

<n> gross/net status 'G' = Gross weight

 'T' = Tare weight

 'N' = Net weight

<m> Motion status 'M' = scale is in motion

 <space> = scale is stable

<f> Future use <space> = always a space

SMA “W” Test

Send <LF>W<CR>

<LF><s><r><n><m><f><xxxxxx.xxx><uuu><CR>

[Hercules](#)

Send	
0A570D	☒ HEX Send
<LF>W<CR>	☐ HEX Send
#010#087#013	☐ HEX Send

W

1G

41b

Avery Weigh-Tronix

A/B About Commands

A and B commands are used together to get general scale info

A returns the 1st response

B must be sent successively to get the 2nd, 3rd, 4th, 5th and 6th
<LF><xxx>:<yyyy><CR>

1st response: <xxx> = "SMA" <yyyy> = compliance level/revision

2nd response: <xxx> = "MFG" <yyyy> = manufacturer

3rd response: <xxx> = "MOD" <yyyy> = model name

4th response: <xxx> = "REV" <yyyy> = software revision

5th response: <xxx> = "SN " <yyyy> = indicator serial number

6th response: <xxx> = "END" <yyyy> = end of About

I/N Info Commands

I and N commands are used together to get detailed scale info
I returns the 1st response

N must be sent successively to get the 2nd, 3rd, 4th, 5th and 6th

<LF><xxx>:<yyyy><CR>

I 1st response: <xxx> = "SMA" <yyyy> = compliance level/revision

N 2nd response: <xxx> = "TYP" <yyyy> = 'S' for Scale mode ('C' if Classifier)

N 3rd response: <xxx> = "CAP" <yyyy> = uuu:ccc:n:d where

uuu = unit of measure

ccc = capacity of the scale

n = count-by increment

d = decimal point position

'0' = none '1' = xxxx.x, '2' = xxx.xx, etc.

N 4th response: <xxx> = same as 3rd response (multi-interval mode n/a)

N 5th response: <xxx> = "CMD" <yyyy> = "PTMCU"

list of supported SMA commands.

Level 1 commands are not included in the list. **Avery Weigh-Tronix**

N 6th response: <xxx> = "END" <yyyy> = end of Info

Special SMA Level 2 commands

<LF>XA<CR> Accumulate command

ACCUM or COUNT app will perform Accumulation

Same as pressing the **PRINT** key

Ports binded to Type = Print will send configured response

Port that initiated command will receive <LF>xa<CR>

<LF>XB<CR> Print command

Same as pressing the **PRINT** key

Ports binded to Type = Print will send configured response

Port that initiated command will receive <LF>xb<CR>

ENQ & Broadcast Commands

A	ACCUM command	"If ACCUM APP is active this command will generate an accumulation transaction, but it does not perform the print function"
P	PRINT command	"Performs same function as pressing the PRINT key. All Ports that are binded with PRINT type will transmit the assigned print format"
S	SELECT command	Performs same function as pressing the SELECT key
T	TARE command	Performs same function as pressing the TARE key
U	UNITS command	Performs same function as pressing the UNITS key
Z	ZERO command	Performs same function as pressing the ZERO key
F	F1 command	Performs same function as pressing the F1 key

Application variables used in print formats only get updated by a **Print** command

ENQ character will not update application variables

Upper or Lower case characters work the same

Avery Weigh-Tronix

NCI Commands

W <Cr>	Weight request	Returns decimal weight, units and status
S <Cr>	Status request	Returns status.
Z <Cr>	Zero request	Scale is Zeroed and returns scale status
H <Cr>	High Resolution Weight request	"Returns decimal wt in 10x or x100 resolution with units and status. For x100 resolution set the associated PROT > ATTR > ENQ menu value to 100. For all other values the H command will return x10 resolution"
U <Cr>	Units request	Changes unit of measure and then returns decimal weight in the new units with status.
M <Cr>	Metrology Raw Counts request	Returns normalized raw counts and scale status.
T <Cr>	Tare request	Scale is Tared and returns scale status.
all else	Unrecognized command	Returns <Cr> ? <Lf>

Avery Weigh-Tronix

Remote RD Commands

Incoming commands from the Master indicator that control the Remote display annunciators

G	Gross	Change to Gross weight mode
N	Net	Change to Net weight mode
T	Tare	Change to Tare weight mode
l	lb	Change to Unit 1
k	kg	Change to Unit 2

Outgoing key press commands from the Remote display that control the Master indicator operation.


T	TARE
S	SELECT
Z	ZERO
P	PRINT
U	UNITS
F	F1

Key press commands are supported by COM 1 and 2 only

Avery Weigh-Tronix

Input & Output

Enable ON/OFF



Inputs defined in SUPER menu


None, Print, Units, Select, Tare, Zero,
F1, Accumulate, Print hold, User

Outputs OFF by default

Must be enabled to test

Avery Weigh-Tronix


Supervisor Menu - 1793



These menu items are available in all applications

Avery Weigh-Tronix


Remote Inputs



Inputs can be voltage free or digital signal (PLC) up to +7Vdc **Avery Weigh-Tronix**

Entering Setpoint Values

Press and hold
SELECT key




Setpoints Outputs

	Below Value	Above Value
General	OFF	ON
Accumulator	OFF	ON
Count	OFF	ON
Checkweigher	SP1 - UNDER SP2 - ACCEPT SP3 - OVER	
Batching	ON	OFF
Peak Hold	OFF	ON
Remote Display	OFF	ON

Setpoint Annunciators



ZM201 – SD2 / SP2



ZM201 – PD2

Annunciators operation can be inverted from physical Output

Avery Weigh-Tronix

Setpoint Output Controls

3 Built-in Outputs

FET's capable of sinking up to 250ma
no optical isolation
recommend the OPTO-22 option

Opto module

Solid state switching device

Relay

Electro-mechanical switching device


On-board 5VDC

TB3-6 rated at 500ma
PTC - resettable fuse protected
(Positive Temperature Coefficient)

Outputs must be enabled in SETUP > OUTPUT menu

Avery Weigh-Tronix

Typical SP Output Connection




Ideal for SSR, Opto-22, Reed or EM relays to drive larger current devices.
or

Direct connection to small DC servo motors, stack lights, low current devices

Avery Weigh-Tronix

Applications



Applications Overview

- General Weighing is default Application
- Application selection in SETUP > SYSTEM > APP menu
- Only 1 APP can be enabled
- Most application settings configured in SUPER menu
- Setpoint OUT values can be entered using SELECT
(Press & Hold)
- 1793 password can not be changed

General Weighing

F1 No Function

SELECT Scroll thru Gross, Net and Tare

Default Printout = Print Format # 1
Com Port 1 9600 Baud

Gross	272.04	lb
Tare	95.88	lb
Net	176.16	lb


Avery Weigh-Tronix

Accumulator

SELECT Scroll thru Gross, Net, Tare, Gross Total, Net Total, Transaction Count.

ANNUNCIATORS	Gross Total	GROSS and TOTAL
	Net Total	NET and TOTAL
	Transaction Count	TOTAL

NOTE: Auto Accumulate enabled in SETUP > PORTS > INTERL will also Autoprint



Avery Weigh-Tronix

Accumulator Printouts

F1 Press to Accumulate only

PRINT Press to Print and Accumulate

Default printout = Print Format # 2

Transaction Count: 10

Gross 272.04 lb

Tare 95.88 lb

Net 176.16 lb

Press and Hold to print Total

Accumulator Total printout = Print Format # 8

Transaction Count: 10

Gross Total 1357.12 lb

Tare Total 356.24 lb

Net Total 1000.88 lb

Avery Weigh-Tronix

Counting

F1

Start Sample

Zeroes > Enter # parts > Add parts > Press F1


Dribble mode only → count sample parts on scale

Minimum Sample weight is Gross Zero Band (GZB)

Count mode also has Accumulator

SELECT

Scroll thru Gross, Net, Tare, Count, Count Total, Transaction Total and Piece Weight



Avery Weigh-Tronix

Count Printouts

PRINT Press to Print and Accumulate

Default printout = Print Format # 3

Count	174
-------	-----

Press and Hold to print Total = Print Format # 9

Transaction Count: 10
Count Total 176

Avery Weigh-Tronix

Target

F1

Set Accept Zone using Sample weight or Limit entry

Sample method > With item on scale press F1

Under & Over division values set the Accept Zone
(set prior to performing Sample)


Limit method > With weight below Gross Zero Band

Display prompts to enter LO & HI limit values

Accept Zone between Limit values

SELECT

Scroll thru Gross, Net and Tare



Avery Weigh-Tronix

Target Operation

Check weighing based on NET weight

Latched method for outputs > stable weight sets condition
Outputs & Annunciators unchanged until $wt < GZB$

Under & Over Bar Graph segments fixed at 1 division each

Outputs & Annunciators OFF when weight < GZB

[Check Weighing](#)


Default printout = Print Format # 4

Net 12.34 lb

Avery Weigh-Tronix

Batch – 3 Ingredient

- F1** Start and Stop batch operation
- SELECT** Scroll thru Gross, Net and Tare
Press & Hold to enter Setpoint OUT values
- MODE** AUTO > Sequence thru ingredient setpoint automatically
MANUAL > Stops after each ingredient > Press F1 again
- DISP** NET > Fill based on Net weight
Tare to start and in between ingredients
GROSS > Fill based on Gross weight



Avery Weigh-Tronix

Batch Operation

Pressing **F1** to Stop a Batch forces a restart of entire batch

Gross filling mode uses accumulated weight entry for successive setpoint values

Ingred 1 = 10, Ingred 2 = 20, Ingred 3 = 30

Out 1 = 10, Out 2 = 30 (10 + 20) and Out 3 = 60 (10 + 20 + 30)

No Preact (in-flight) in 200 series

Bar Graph will indicate batching progress for each ingredient



Default printout = Print Format # 5

G **12.34 lb**

[3 Ingredient Batching](#)

Avery Weigh-Tronix

Custom Batch Printout

SP1

{A.4.1}

Actual

{A.10.1}

Ztools Advance Print Format

{T.UNIT.1}

#CR

#LF

SP2

{A.5.1}

Actual

{A.11.1}

SP1	10	Actual	10.02 lb
SP2	20	Actual	20.04 lb
SP3	30	Actual	30.06 lb

{T.UNIT.1}

#CR

#LF

SP3

{A.6.1}

Actual

{A.12.1}

{T.UNIT.1}

#CR

#LF


#LF

Avery Weigh-Tronix

Peak Hold

F1 Reset Maximum Peak weight to current gross

SELECT Gross and Peak weight



← This annunciator
lights for peak
weight

Default printout = Print Format # 6

Peak Gross 1000.02 lb


Avery Weigh-Tronix

Remote Display

Remote indicator will display the primary indicator information

TARE, SELECT, PRINT, UNITS, ZERO, F1 keys are functional


SETUP > PORTS > PROTCL > TYPE x = RD and BIND x = PORT 1 or 2




[Remote Display](#)

Avery Weigh-Tronix

ZM201-PD2 Battery Pack






Battery Kit works for both ABS & SST
Extra bracket for SST model only



Avery Weigh-Tronix

ZM201 SST Battery Pack



Avery Weigh-Tronix

ZM201 SST Battery Pack



Avery Weigh-Tronix

ZM201 P3 ON/OFF Jumper



Jumper on P3

P3



Front panel **ON/OFF**
key will not function



Jumper off P3

P3



Front panel **ON/OFF**
key will function

ZM201 Battery Pack

8 x 1.2v Nickel Metal Hydride (NiMH) = 9.6 volt

18 hr continuous operation with single load cell

14-16 hr with 4 load cells

Extended using Sleep timer

5 hr recharge time

500 recharges

[Battery Timer Enable](#)

ZM201 Sealing Kit

Sealing kits for ABS & SST

[ZM201 Sealing Kit](#)

Avery Weigh-Tronix

ZM201 SP0 – Modbus TCP

Fixed Output Mapping

Tag Name	Address
Gross	001
Tare	003
Net	005
Motion	007
CenerZero	009
OverUnder Flag	011
HeartBeat	013
ConfigCounter	015
CalibCounter	017
HiResGross	019
calZeroDone	021
calSpanDone	023
PbZero Done	025
PbTareDone	027

Fixed Input Mapping

Tag Name	Address
PbZero	125
PbTare	127
KeypadTare	129
calZero	131
calSpan	133
calWeight	135

Fixed character format
32 bit : unsigned double word
Endian Format : Little
Trade : Off

Avery Weigh-Tronix

SMA Level 2 Calibration commands

Supported by all ZM201 models

<LF>XZ<CR> Cal Zero command

The scale responds with a standard scale response.

If the “Set Zero” operation fails then the scale responds with the <s> field = “0”

<LF>XS<CR> Cal Span command


The scale responds with a standard scale response

If the “Set Span” operation fails then the scale responds with the <s> field = “s”


<LF>XC<CR> Get Audit Counters command

The scale responds with <LF>Calib:123456:Config:9876:<CR>

ZM205 Baggage Scale



ZM205 model select jumpers



ZM205 Baggage Scale – Key Functions

Key	Description
	Press the CE/C* key to cancel the previous accumulator or hold the key to clear all accumulators. Also acts as an up arrow key when in the menu structure.
	Press the M- key to subtract the last bag from the total. Also acts as a Left arrow key when in the menu structure.
	Press the M+ key to accumulate. Also acts as a Right arrow key in the menu structure

No TARE, PRINT, UNITS or ON/OFF key

TARE -> CE/C

M+ -> PRINT

M- -> UNITS

Avery Weigh-Tronix

ZM205 Setup Menu - Differences

SYSTEM Menu -> No TARE or APPS selection

PORTS > PROTCL -> for Serial Ports only

PORTS > OPTIONS added for ProfiBus & Relay

ZM205 Operation

Ethernet Port used for Remote display connection


Master / Remote settings are defaulted

M+ adds new bag weight to Accumulator

M- subtracts last bag weight from Accumulator

F1 shows accumulated value

ZM205 POE to Remote




Ethernet Current Limiting board:
Installed on both the main and remote indicator PC boards at the factory.

**DO NOT CONNECT ETHERNET
WITHOUT THIS BOARD IN PLACE!**

Avery Weigh-Tronix

ZM205 Option Menu – ProfiBus or Relay

ProfiBus registers match the E1020
Uses DP-V1 Standard interface




[Profibus](#)

[Relay](#)

Avery Weigh-Tronix

ZM205 SUPER Menu



ZM205 Setpoints

The OVER annunciator is tied to both setpoint OUT 1 and OUT 3 values
If weight exceeds OUT 1 or 3 the OVER annunciator will light

When Relay option is installed, it is triggered by OUT 3 value
If weight exceeds OUT 3, the relay will trigger a peripheral device



Avery Weigh-Tronix

ZM205 Option Board Installation



Avery Weigh-Tronix

ZM205 Options – ProfiBus

OUT	IN
Gross (scaled)	Remote Zero
Motion 0x00 when stable, 0xFF when motion	
Healthy (see note below) Bit 0 = No Fault (logical 'and' of all bits in the word) Bit 1 = A/D O.K. Bit 2 = Ram O.K. Bit 3 = EEPROM O.K. Bit 4 = CPU O.K. Bit 5 = not Overload (bit to be set to "0" when the over range indication occurs. That is when all "-----" appear) Bit 6 = not Underload (bit to be set to "0" when the under range indication occurs. That is when all "-----" appear) Bit 7 = not Asleep Bits 8 to 15 = set to a "1"	

HEALTHY Status: If everything is working then all bits will be set to a "1"
 If bit "0" changes to a "0" then check state of Bit7 for true fault or "Sleep mode".


Avery Weigh-Tronix

ZM205 Options – ProfiBus



Avery Weigh-Tronix

ZM205 Options – ProfiBus



Output data is to E1020A and changing any of the bits will cause the E1020A to tare off

Input data from E1020A is 3 x words

Word 1 in the picture represents a weight of 17.6kg

Word 2 is stability all 0's = stable all 1's = unstable

Word 3 is healthy status all 1's is good an example of under range is 11111111

10111110

Avery Weigh-Tronix

ZM201 vs ZM300

IP Rating	66	69K
Gore vent	no	yes
Annunciator Desc	panel	display graphics
Navigation arrows	larger	smaller
Large TN display	yes (ABS)	no
# of Load Cell	4	6
Division Size	.00001 to 50	.000001 to 500
Units of measure	2	4 (lb, kg, g, oz & lb-oz)
Custom Unit	1	4
Display update rate max	10	20
# of Protocols	3	5
Print Formats	10	40
Bytes per print format	250	1000
Baud rate max	19200	115200

Avery Weigh-Tronix

ZM201 vs ZM300

COM 1 CTS/RTS	no	yes	
Ethernet Connections	1	5	
Accumulator Channels	1	10	
USB Host	no	yes	no USB printer drivers
ID Entry	no	ZM303	
Audit trail	CAT2	CAT3	no printing in ZM201
Archive report	no	yes	
FTP	no	yes	
Transaction memory	no	yes	USB transfer
Ethernet/IP	no	yes	
Modbus TCP	no	yes	
DHCP default	OFF	ON	> OFF in next rev

ZM201 vs ZM300

Power supply	20W	65W
Numeric Tare entry	yes	ZM301 yes in next rev
ZM201 notes		
SMA	does not support Set & Get level 2 commands	
Options	no Wireless, Analog Output, RS485, USB-Device	
Setpoints	no active above/below selection	
Counting	dribble sample mode only	
Checkweighing	latch mode only	
Batch	3 Ingredient only : no preact, 2-speed, fill/discharge	
Remote Display	Basic only – no 350IS	
Checkweigher Units	Porex plug installed for shipping	
Panel Mount	Barrel plug to 2 terminal screw lug for DC power input	



ZM 200 Series Training

The End

Any Questions?

Thank you for attending!

Avery Weigh-Tronix

